



P U M P S

Aluminum Center PTO Pumps



FEATURES:

- Cast iron end plates with aluminum center section
- Self-adjusting wear plates
- Tapped holes for a torque arm kit to prevent pump rotation
- Hose barb for inlet port & NPT adapter for outlet port
- Slips onto tractor PTO shaft (no gear box required)

MODEL NUMBER	DISPLACEMENT CU. IN/REV	RPM	DRIVE SHAFT	INLET PORT	OUTLET PORT	"A"	"B"	GPM OUTPUT (Full RPM)	INLET ADAPTER	WT. LBS.	SEAL KIT PART #	LIST PRICE
WP-PTO-1A	9.8	540	6 TOOTH	SAE #16	SAE #12	2.4	6.3	21	1/4" HOSE	45	PMCK-WP-PTO-SS	914.63
WP-PTO-2A	5.5	540	6 TOOTH	SAE #16	SAE #12	1.6	5.6	11	1" HOSE	41	PMCK-WP-PTO-SS	853.66
WP-PTO-7A	3.6	540	6 TOOTH	SAE #16	SAE #12	1.3	5.2	7	1" HOSE	37	PMCK-WP-PTO-SS	853.66
WP-PTO-8A	3.6	1000	21 TOOTH	SAE #16	SAE #12	1.3	5.2	13	1" HOSE	38	PMCK-WP-PTO-SS	853.66
WP-PTO-9A	7.6	540	6 TOOTH	SAE #16	SAE #12	2.0	6.0	17	1/4" HOSE	43	PMCK-WP-PTO-SS	853.66
*WP-PTO-K11	9.8	1000	21 TOOTH	SAE #20	SAE #16	2.4	6.3	40	2" HOSE	45	PMCK-WP-PTO-RR	914.63

* Ports on WP-PTO-PK11 are located facing rear of the pump

