RD5000 VALVE, TYPICAL SPOOL ATTACHMENT LOAD CHECK-HANDLE BRACKET HANDLE KIT-RELIEF CARTRIDGE OUTLET PORT OPTION D SPOOL O-RING CLOSED CENTER PLUG POWER BEYOND PORT OPTIONS C & F - SPOOL BACKUP POWER BEYOND PLUG NOTE: FEATURES MAY VARY WITH OPTION B MODEL NO., CONSULT CATALOG OPEN CENTER PLUG

RD5200 2 SPOOL MONO-BLOCK VALVE SHOWN. RD5100 & RD5300 ARE SIMILAR.

CLOSED CENTER PLUG, OPTION D:

This option provides for closed center operation. This is typically used with a variable displacement pressure compensated pump or in a system with an unloading valve. When the spools are in neutral the inlet port is blocked. The power beyond plugs can be used for closed center conversion by plugging the power beyond port. PLEASE NOTE: It may be necessary to increase the relief pressure above pump compensator setting.

POWER BEYOND PLUG WITH 3/4 NPTF (OPT. C) OR #12 SAE (OPT. F): This option provides for a high pressure power beyond port. This would be used if a valve is to be added downstream. PLEASE NOTE: The outlet must be connected to tank. When spools are in neutral the inlet is connected to power beyond port.

3 WAY SPOOLS, OPTION 'A': Have the 'A' work port plugged. Connect 'B' work port to cylinder.

LOAD CHECK:

The load check feature is standard on all RD5000 series valves. Each spool has a separate load check. The load check will prevent the fall of a cylinder as the spool is shifted. It also prevents the backflow of oil from the work port to the inlet. The pump must build up enough pressure to overcome the pressure on the work port caused by the weight of the load before the cylinder can move.

PLEASE NOTE: The load check has nothing to do with how well the valve will hold up a cylinder with the spool in neutral. The load check is functional only when the spool is shifted.

RD5000 KITS AND CARTRIDGES

PART NO.:	DESCRIPTION:
660551001 660552001 660553001 660150004 660150003 660150002 660350001 660150012 660150012 660150014 660150018 660150018 660150020 660150020 660150020 660150020 660150020 660150020 660150020 660150020 660312003 660312004 660312008 660312008 660312008 660250006 6602500003 6602500003	RD5100 SEAL KIT (1 SPOOL) RD5200 SEAL KIT (2 SPOOL) RD5300 SEAL KIT (2 SPOOL) LOAD CHECK KIT STANDARD HANDLE KIT (HANDLE, KNOB & PINS) COMPLETE HANDLE KIT PIN KIT HANDLE CLEVIS SUB—ASSY JOYSTICK HANDLE KIT (BENT) JOYSTICK HANDLE KIT (STRAIGHT) SPRING CENTER KIT 3 POSITION DETENT KIT FRICTION DETENT KIT FRICTION DETENT KIT SPRING CENTER W/FLOAT DETENT KIT (REPAIR ONLY) 1 POS. DETENT SPOOL OUT SPRING CENTER KIT 2 POS. DETENT SPOOL IN AND OUT SPRING CENTER KIT 1 POS. DETENT SPOOL IN SPRING CENTER KIT 1 POS. DETENT SPOOL IN SPRING CENTER KIT 1 CONVERSION PLUG, OPEN CENTER (OPTION B) 3/4—NPTF POWER BEYOND PLUG (OPTION C) #12 SAE POWER BEYOND PLUG (OPTION F) CLOSED CENTER CONVERSION PLUG (OPTION D) NO—RELIEF PLUG (OPTION 1) ADJUSTABLE RELIEF CART. 500—1500 PSI (OPTION 4) ADJUSTABLE RELIEF CART. 1500—3000 PSI (OPTION 5) RELIEF: STANDARD SETTING OPTIONS 3 & 5; 2000 PSI STANDARD SETTING OPTIONS 2 & 4; 1000 PSI

REV. A; ECN-18645 12/06/05 REV. B; ECN-21619 1/9/12

